

# International Torque Chart

Model	Horse Power @ RPM	Torque @ RPM
530	250 @ 2200	800 @ 1300
530	275 @ 2200	860 @ 1300
530	300 @ 2200	950 @ 1300
444E	175 @ 2600	460 @ 1400
444E	195 @ 2600	520 @ 1400
444E	210 @ 2600	540 @ 1500
444E	215 @ 2600	560 @ 1400
444E	230 @ 2600	620 @ 1400
DT 408	175 @ 2600	430 @ 1800
DT 408	190 @ 2600	485 @ 1800
DT 408	210 @ 2600	520 @ 1800
DT 408	230 @ 2600	605 @ 1800
DT 466	195 @ 2400	520 @ 1600
DT 466	195 @ 2600	520 @ 1400
DT 466	210 @ 2400	605 @ 1600
DT 466	215 @ 2600	540 @ 1400
DT 466	215 @ 2600	560 @ 1400
DT 466	230 @ 2400	660 @ 1600
DT 466	230 @ 2600	620 @ 1400
DT 466	250 @ 2400	660 @ 1600
DT 466	275 @ 2400	800 @ 1600
DT 466 HT	215 @ 2400	620 @ 1400
DT 466 HT	230 @ 2400	660 @ 1400
DT 466 HT	250 @ 2400	800 @ 1400
DT 530	275 @ 2200	800 @ 1200
DT 530	300 @ 2200	950 @ 1200
DT 530	330 @ 2200	950 @ 1200
HT 530	280 @ 2000	950 @ 1200
HT 530	300 @ 2000	1050 @ 1200
HT 530	320 @ 2000	1150 @ 1200
HT 530	340 @ 2000	1200 @ 1200
T444E	160 @ 2600	400 @ 1500
T444E	175 @ 2600	430 @ 1500

Model	Horse Power @ RPM	Torque @ RPM
T444E	190 @ 2600	485 @ 1500
VT 365	175 @ 2600	460 @ 1400
VT 365	195 @ 2600	520 @ 1400
VT 365	215 @ 2600	540 @ 1400
VT 365	230 @ 2600	620 @ 1400